


EASILY TEST YOUR CABLES TO SAVE DIAGNOSTIC TIME



Unidapt™ WiFi Coax and Cat 5 Testing Kit
RFA-4028-WIFI

Unidapt™ WiFi Testing Kit
RFA-4018-WIFI



CONTENTS OF Unidapt™ TESTING KITS

Description (interface to Unidapt™ interface)	Unidapt™ Testing Kit RFA-4018	Unidapt™ WiFi Testing Kit RFA-4018-WIFI	Unidapt™ Coax & Cat 5 Testing Kit RFA-4028	Unidapt™ Coax & Cat 5 WiFi Testing Kit RFA-4028-WIFI	Part Number
Universal Adapters	6	6	6	6	PT-4000-013
BNC Male	2	1	2	1	PT-4000-004
BNC Female	2	1	2	1	PT-4000-010
N Male	2	2	2	2	PT-4000-003
N Female	2	2	2	2	PT-4000-009
SMA Male	2	2	2	2	PT-4000-006
SMA Female	2	2	2	2	PT-4000-012
TNC Male	2	2	2	2	PT-4000-005
TNC Female	2	2	2	2	PT-4000-011
UHF Male	2		2		PT-4000-001
UHF Female	2		2		PT-4000-007
Mini-UHF Male	2		2		PT-4000-002
Mini-UHF Female	2		2		PT-4000-008
MMCX Male		1		1	PT-4000-117
MMCX Female		1		1	PT-4000-118
RP-SMA Male		2		2	PT-4000-133
RP-SMA Female		2		2	PT-4000-134
RP-TNC Male		2		2	PT-4000-135
RP-TNC Female		2		2	PT-4000-136
Unidapt™ Cable Tester	1	1	1	1	RFA-4018-20
Cat 5 Cable Tester			1	1	RFA-4218-20

Unidapt™ Cable Tester (RFA-4018-20) Features

- Powered by a 9-volt battery.
- Lightweight, small & completely portable.
- LED panel on front of tester indicates Pass or Fail.
- If Fail, panel saves valuable diagnostic time by indicating whether due to Short, Open Conductor or Open Shield.


Using Cable Tester

- To **Test free cables**, attach each end of cable assembly to tester.
- Cable condition will be indicated on LED panel.
- Test **Installed cables** with two Coaxial Cable Testers.
- Disconnect cable from all equipment and attach remote cable end to right jack of one tester. Attach the local cable end to left jack of local tester.
- Cable status will be displayed on LED panel of local tester.

Unidapt™ Cable Testing Kits


KITS: Unidapt™ Universal Adapter System

Unidapt™ Testing Kit:




Unidapt™ Testing Kit RFA-4018

=



UNIDAPT™ CABLE TESTER


+



Classic Kit RFA-4024


page 106

Unidapt™ WiFi Testing Kit:



Unidapt™ WiFi Testing Kit RFA-4018-WIFI

=



UNIDAPT™ CABLE TESTER

+



Classic WiFi Kit RFA-4024-WIFI

page 106

Unidapt™ Coax & Cat 5 Testing Kit:



Unidapt™ Coax & Cat 5 Testing Kit RFA-4028

=



Unidapt™ Cable Tester

+



Cat 5 Cable Tester

+



Classic Kit RFA-4024

page 101

page 106

Read about our Cat 5 cable tester on page 101

Our coaxial cable tester with BNC adapters is shown on page 121

Unidapt™ WiFi Coax & Cat 5 Test Kit:



Unidapt™ WiFi Coax & Cat 5 Test Kit RFA-4028-WIFI

=



Unidapt™ Cable Tester

+



Cat 5 Cable Tester

+



Classic WiFi Kit RFA-4024-WIFI

page 101

page 106

INDIVIDUAL ADAPTERS are shown at 65% actual size

See complete list of Unidapt™ adapters on page 117

The Key!



7610 Miramar Road, San Diego, CA 92126 • (858) 549-6340 • (800) 233-1728
 fax: (858) 549-6345 • email: rfi@rfindustries.com • web: www.rfindustries.com

KITS

KITS