


Kits Expand UNIDAPT™ Line

The RFA-4022, 74-piece Unidapt™ Mega-Plus Kit, contains all adapters found in our classic RFA-4024 Unidapt™ Kit, plus 34 additional parts: two 48" Unicables™, Unidapt™ female-to-female barrel adapter, the Unidapt™ Cable Tester, three more universal adapters and an assortment of reverse polarity adapters. 

RFA-4018-20 Unidapt Cable Tester — available separately or in Unidapt™ test kits. Powered by a 9-volt battery, tester is lightweight, small and completely portable. Front LED panel indicates Pass, Fail, Short, Open Conductor or Open Shield. You can use any combination of Unidapt™ adapter to create literally hundreds of configurations. No other coaxial tester on the market offers this versatility.

RFA-4019, 27-piece Unidapt Expansion Kit — for current Unidapt™ owners. Contains 3 universal centers, all of the new adapters (SMB, MCX, MMCX, 7-16 DIN, RP-SMA, RP-TNC) and expansion slots to house your current adapters in one convenient foam-lined case.

RFA-4019-48 — RFA-4019 with two 48" Unicables™ and Unidapt™ Barrel Adapter.

RFA-4020, 70-piece Unidapt Mega Kit — contents of RFA-4023-01 kit plus all new adapters (SMB, MCX, MMCX, 7-16 DIN, RP-SMA, RP-TNC).

RFA-4018, 31-piece Unidapt Cable Testing Kit — contents of Classic RFA-4024 kit plus Unidapt™ coaxial cable tester. Bench and field technician can quickly and easily test cables with female Mini-UHF, TNC and male and/or female BNC, N, or SMA terminations.

RFA-4018-WIFI Unidapt Cable Testing Kit — contains Unidapt™ coax cable tester with these male and female connector interfaces: RP-TNC, RP-SMA, MMCX, N, TNC, BNC, and SMA.

RFA-4018-20 Unidapt Cable Tester

RFA-4023-01, 43-piece Unidapt Universal Adapter Kit — includes RF Sampler, right-angle and "T" adapters, binding posts, banana plugs, and RCA and F connectors.

RFA-4023-01-WIFI — components of RFA-4024-WIFI kit, plus "T" & R/A universal centers, RF Sampler, binding post and banana plug adapters, RCA and F adapters.

RFA-4028 Expanded Unidapt Cable Testing Kit —


components of RFA-4018 kit with RFA-4218-20 CAT5 cable tester.

RFA-4028-WIFI Expanded Unidapt Cable Testing Kit —

components of RFA-4018-WIFI kit and the RFA-4218-20 CAT5 cable tester.

RFA-4218-20 CAT5 Cable Tester — EIA/10Base-T tester with RJ45 inputs and LED display. Tests 10Base-T pairs, Straights, Crossovers and Miswires.

Unidapt™ is a registered trademark of RF Industries.




RFA-4018-20 Unidapt™ Cable Tester



RF Connectors, Div. of RF Industries, 7610 Miramar Road, San Diego, CA 92126-4202
Toll Free: (800) 233-1728 or (888) 775-2372 Phone: (858) 549-6340 Fax: (858) 549-6345
Email: rfi@rfindustries.com Web: www.rfindustries.com

RFA-4028-WIFI Unidapt™ Kit

Connector Identifier



CONTENTS

- | | |
|--|---|
| (2) PT-4000-003
<i>Unidapt Fem. to N Male</i> | (1) PT-4000-117
<i>Unidapt Fem. to MMCX Male</i> |
| (1) PT-4000-004
<i>Unidapt Fem. to BNC Male</i> | (1) PT-4000-118
<i>Unidapt Fem. to MMCX Fem.</i> |
| (2) PT-4000-005
<i>Unidapt Fem. to TNC Male</i> | (2) PT-4000-133
<i>Unidapt Fem. to RP SMA Male</i> |
| (2) PT-4000-006
<i>Unidapt Fem. to SMA Male</i> | (2) PT-4000-134
<i>Unidapt Fem. to RP SMA Fem.</i> |
| (2) PT-4000-009
<i>Unidapt Fem. to N Fem.</i> | (2) PT-4000-135
<i>Unidapt Fem. to RP TNC Male</i> |
| (1) PT-4000-010
<i>Unidapt Fem. to BNC Fem.</i> | (2) PT-4000-136
<i>Unidapt Fem. to RP TNC Fem.</i> |
| (2) PT-4000-011
<i>Unidapt Fem. to TNC Fem.</i> | (1) RFA-4018-20
<i>Unidapt Cable Tester</i> |
| (2) PT-4000-012
<i>Unidapt Fem. to SMA Fem.</i> | (1) RFA-4218-20
<i>Cat-5 Cable Tester</i> |
| (6) PT-4000-013
<i>Unidapt Male Universal Centers</i> | |